

MG C6 Cupholder Pod Installation

1. Remove center console piece. Should be write ups for this out there already if you dont know how.
2. Unbolt the stock cupholder, it will be four screws.
3. Install gauges or gauge into pod before installation.
4. Install MG gauge pod with four screws you removed from the stock unit.
5. Run wires up to center console area for gauges or switches.
6. Plug everything in and test it before snapping the console back into place.
7. Snap console back into place.
8. Sit back and admire your new gauge install. Be sure to also send us some pics after installation.

Motor Gremlin LLC.

Check us out at motorgremlin.com

